How to change the admin password on your NETGEAR® router

Note: This password is not the password that you use to access your Wi-Fi®





STEP 1: Open any web browser and enter 192.168.1.1 or http://www.routerlogin.net/ in the address bar. Enter the Username (admin) and Password (password) to access the router configuration page. Click on Advance tab.



STEP 2: Select Set Password under Administration.

STEP 3: Key in both Old Password (password) and New Password.

To be able to recover your password in future, select **Enable Password Recover** checkbox. Click **Apply** to save the changes. The new password will be needed during your next sign-in to NETGEAR[®] Web (Desktop) and NETGEAR[®] Apps (iOS & Android[™]).

That's it!

You should be getting wireless connectivity from your router in a few minutes. Enjoy your super fast ViewQwest connection! If you're unable to connect to the internet after completing the setup, or have any difficulties during the setup, please contact our setup support team at:

3102 0000 (Select technical support option) Phone support is only available from 9am-7pm (Mon to Fri). Kindly note that any on-site visit to your home for setup support, independent of NetLink Trust Fibre High-Loss or hardware failure, will be chargeable at \$80 per visit.



Call us at 3102 0000 or e-mail: residential.support@viewqwest.com Visit us at www.viewqwest.com Suntec Store: 3 Temasek Boulevard #-2-414/415, Suntec City Mall, Singapore 038983 Sim Lim Booth: 1 Rochor Canal Road, Sim Lim Square Level 1, Singapore 188504 Showroom: 200 Bukit Timah Road, Singapore 229862



STEP-BY-STEP GUIDE ON HOW TO SET UP NETGEAR® ROUTER FOR WIRELESS CONNECTIVITY

Kindly ensure that the ViewQwest modem is connected to the NETGEAR® Router before proceeding to configure your router for wireless connectivity. (Refer to ViewQwest user manual)





Step 1a: Connect the ViewQwest modem to the router's WAN port.

Step 1b: Connect your laptop to the router's LAN port or to the router's Wi-Fi® using the preset wireless settings found on the router.

neme (SSIC) and network key (password)	
LAR56	
EAR19-60	
rplano811	
01	058855 05885-00 2wpiero811

STEP 3: The internet connection and wireless connectivity will be configured automatically. **Network Name** (SSID) and **Password** will also be generated automatically for your wireless connection [You may change the Network Name (SSID) and Password later]. Click **Next** to proceed.



To view this page, you must log in to this area on www.routerlogin.net.80:

1

Cancel

NETOEAR R7000

Checking the Internet co

NETGEAR'

Nighthawk(R) X4S R78(

STEP 4: Select the checkbox and click **Next** to install NETGEAR® genie® app, else click Exit to complete the setup. It is highly recommended to download NETGEAR® genie® app to monitor your home network.

0.0.0	Join "NETGEAR59-50"	
NETGEAR Nighthawk(R) X4S R76		
Firmware Upgrade Assista	ıt	
A new version has been found. Do Yo	want to upgrade to the new version now?	
Current Version: New Version:		V1.5.0.40 V1.5.2.40
Current GUI Language Version: New GUI Language Version:		V1.0.0.261 V1.0.0.269
	Yes No	
3	www.stuteriogin.net	Can

STEP 5: You will be prompted to update the firmware if a new version is available. However, it is recommended to skip this step first, and proceed with the setup. You can do the update after the internet connection is successfully configured.



STEP 6: Upon successful setup, the **Completed Installation** page will appear. You are now ready to surf wirelessly with Singapore's fastest fibre broadband family!

How to change Wireless Network Name (SSID) and Password



STEP 1a: Open any web browser and enter 192.168.1.1 or **http://www.routerlogin.net/** in the address bar.

STEP 1b: Enter the **Username (admin)** and **Password (password)** to access the router configuration page.

STEP 1c: Click on Wireless tab under Basic tab.



STEP 2: There will be two wireless networks [(A) **2.4GHz** and (B) **5.0GHz**] available for configuration. Key in new **Name (SSID)** and **Password (Network Key)** for each wireless network, and click **Apply** to save the changes.

NETGEAR and the NETGEAR logo are trademarks of NETGEAR, Inc. Any other trademarks are for reference purposes only. ©2015 NETGEAR, Inc. Wi-Fi® is a trademark of Wi-Fi Alliance. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. Android[™] is a trademark of Google Inc.